


# Flashwriter II

Users Guide



**VECTOR GRAPHIC INC.**

FLASHWRITER II BOARD

Manual Revision 3  
March 29, 1979

Copyright 1979 Vector Graphic Inc.

Copyright 1979 Vector Graphic Inc.

**Revision Numbers**

The revision number and date of release of each page herein appears at the bottom of each page. The revision number and date of release on the Title Page corresponds to that of the page most recently revised.

Vector Graphic Flashwriter II Board

REPAIR AGREEMENT

The Flashwriter II Board sold hereunder is sold "as is", with all faults and without any warranty, either expressed or implied, including any implied warranty of fitness for intended use or merchantability. However, the above notwithstanding, VECTOR GRAPHIC, INC., will, for a period of ninety (90) days following delivery to customer, repair or replace any Flashwriter II Board that is found to contain defects in materials or workmanship, provided:

1. Such defect in material or workmanship existed at the time the Flashwriter II Board left the VECTOR GRAPHIC, INC., factory;
2. VECTOR GRAPHIC, INC., is given notice of the precise defect claimed within ten (10) days after its discovery;
3. The Flashwriter II Board is promptly returned to VECTOR GRAPHIC, INC., at customer's expense, for examination by VECTOR GRAPHIC, INC., to confirm the alleged defect, and for subsequent repair or replacement if found to be in order.

Repair, replacement or correction of any defects in material or workmanship which are discovered after expiration of the period set forth above will be performed by VECTOR GRAPHIC, INC., at Buyer's expense, provided the Flashwriter II Board is returned, also at Buyer's expense, to VECTOR GRAPHIC, INC., for such repair, replacement or correction. In performing any repair, replacement or correction after expiration of the period set forth above, Buyer will be charged in addition to the cost of parts the then-current VECTOR GRAPHIC, INC., repair rate. At the present time the applicable rate is \$35.00 for the first hour, and \$18.00 per hour for every hour of work required thereafter. Prior to commencing any repair, replacement or correction of defects in material or workmanship discovered after expiration of the period for no-cost-to-Buyer repairs, VECTOR GRAPHIC, INC., will submit to Buyer a written estimate of the expected charges, and VECTOR GRAPHIC, INC., will not commence repair until such time as the written estimate of charges has been returned by buyer to VECTOR GRAPHIC, INC., signed by duly authorized representative authorizing VECTOR GRAPHIC, INC., to commence with the repair work involved. VECTOR GRAPHIC, INC., shall have no obligation to repair, replace or correct any Flashwriter II Board until the written estimate has been returned with approval to proceed, and VECTOR GRAPHIC, INC., may at its option also require prepayment of the estimated repair charges prior to commencing work.

Repair Agreement void if the enclosed card is not returned to VECTOR GRAPHIC, INC. within ten (10) days of end consumer purchase.

# Vector Graphic Flashwriter II Board

## TABLE OF CONTENTS

<u>Section</u>	<u>Page</u>
Repair Agreement	
Table of Contents	
I. Introduction	
1.1 Description of the Board.....	1-1
1.2 Description of the Manual.....	1-1
II. Theory of Operation	
2.1 Keyboard Port.....	2-1
2.2 Horizontal Sync Circuitry.....	2-2
2.3 Vertical Sync Circuitry.....	2-2
2.4 Memory Address Multiplexer.....	2-2
2.5 Memory Latch.....	2-3
2.6 Character Generator and Shift Register.....	2-3
2.7 Video Combiner.....	2-3
2.8 Monitor ROM Circuit.....	2-4
III. User's Guide	
3.1 Modifications to the Standard Configuration.....	3-1
3.1.1 Creating a New Character Set.....	3-1
3.1.2 Changing the Address of Video Memory.....	3-3
3.1.3 Putting a Monitor PROM on the Board.....	3-3
3.1.4 Address of the Monitor PROM on the Board.....	3-3
3.1.5 Specifying whether Monitor PROM on Board is 2708 or 2715.....	3-3
3.1.6 Enabling a Jump on Reset.....	3-3
3.1.7 Changing the Keyboard Port Address.....	3-3
3.1.8 Changing the Polarity of the Vertical Sync Signal.....	3-4
3.1.9 Obtaining MWRITE.....	3-4
3.1.10 Changing the Polarity of the Keyboard Strobe.....	3-4
3.1.11 Using Interrupt Driven Software.....	3-5
3.1.12 Supplying a Keyboard with a Negative Voltage Power Supply.....	3-5
3.1.13 Using a Spare Key on the Keyboard for Reset.....	3-5
3.1.14 Accessing the 60 Hz Vertical Blanking Signal.....	3-5

## Vector Graphic Flashwriter II Board

<u>Section</u>	<u>Page</u>
3.2 Programming for the Flashwriter II Board.....	3-6
3.2.1 Vector Graphic Monitors.....	3-6
3.2.2 Displaying Characters Without Using the Vector Graphic Monitor Video Driver.....	3-8
3.2.3 Producing Reverse Video.....	3-8
3.2.4 Determining Whether a Character is in the Keyboard Buffer.....	3-10
3.2.5 Accessing the 60 Hz Vertical Blanking Signal.....	3-10
3.3 Adjusting Your TV Monitor.....	3-10
3.4 Connecting the Board to the Video Display and the Keyboard.....	3-11
3.4.1 Connecting a Video Display Requiring Separate Sync and Video.....	3-12
3.4.2 Connecting a Video Display Requiring Combined Sync and Video.....	3-12
3.4.3 Connecting a Keyboard.....	3-13
IV. Diagrams	
Character Set, Low Order 128 Characters.....	4-1
Character Set, High Order 128 Characters.....	4-2
Blank Form, Low Order Character Set.....	4-3
Blank Form, High Order Character Set.....	4-4
80 X 24 Video Display Module Block Diagram.....	4-5
Board Layout with Jumper Pads.....	4-6
Schematic.....	4-7

## I. INTRODUCTON

### **1.1 Description of the Board**

The Flashwriter II Video Board is Vector Graphic's advanced 80 x 24 memory mapped video board. By "80 x 24" we mean that the board displays characters on the screen in 24 rows of 80 characters each. Each character is made up of an 8 x 10 matrix of dots.

The Flashwriter II can be installed in ANY S-100 8080 or Z-80 computer, including existing Vector Graphic computers, in order to convert the existing memory mapped display to 80 x 24, or to make use of memory mapped video for the first time if a serial terminal had been used. It can be used with almost any standard computer video monitor, since it can produce either separate or combined video and sync signals. However, the monitor must have a band width of at least 12 MHz. The board is definitely applicable to the Vector Graphic Mindless Terminal, which requires separate signals. (Note: in this manual, the word "monitor" refers to a video display unit, and the word "Monitor" with an upper-case M refers to a kind of computer program which handles basic housekeeping functions for the computer.)

The Flashwriter II makes use of the most up-to-date ideas in circuit design such as flicker-free updating of the screen, separate sync outputs for video monitors requiring it, on-board user-programmable PROMs storing the character set, on-board socket for a video-driver and/or Monitor, Jump-on-Reset capability, to be used if the on-board video-driver socket is used, the availability of inverted or non-inverted vertical sync signals, the availability of combined or separate video and sync signals, and the capability for reverse video. To make the board adaptable to many different systems, you are free by using jumpers to specify the memory addresses used by the on-board video memory RAM and the on-board video driver.

Further, a parallel keyboard input port is incorporated on the board, with the port numbers changeable by jumper anywhere from 00 and 01 (status and data) up to 0E and 0F. Although the board is shipped jumpered so that it strobes the keyboard data into the input latch on the rising edge of the key-depression strobe, a jumper can be installed to strobe the data on the falling edge, as required by some keyboards. The board can also be jumpered to generate an interrupt when a key is depressed, instead of waiting to be polled.

A particularly useful feature of the board is the ability to accept a user-created character set, which can be either a 128 or 256 character set. If a 256 character set is desired, then the user must sacrifice the use of reverse video. The board is shipped with a 128 character set, on a PROM. This set consists of the 96 standard ASCII characters and 16 special graphics characters which can be used to build graphics images or large characters.

Instructions are provided for creating your own character set and encoding it on 2708 or 2716 EPROMs (the latter for a 256 character set), if desired.

Instructions are given in this manual for writing programs to use the board. In addition, the user can purchase, if not already included in his computer system, the Vector Graphic Extended Systems Monitor with video driver, Version 3 EV-II. Before making this decision, section 3.2.1 should be read. Use of this Monitor will eliminate some or all of the assembly language programming necessary to use the board. The EVIOS program, a sophisticated video driver used with the Flashwriter I board, canNOT be used with the Flashwriter II board, but Version 3 of the Monitor makes it largely unnecessary. For user's familiar with Flashwriter I, this is partly due to the fact that Flashwriter II does not have a separate memory block containing character attributes. In Flashwriter II, there are no special vertical and horizontal lines outside of those in the graphics characters, there is no reduced intensity, and the graphics characters are produced in response to ASCII codes 00 to 1F and 80 to 9F.

The Flashwriter II board is a major addition to the Vector Graphic product line. Vector Graphic has now applied its well known excellence in video display quality and product flexibility to the creation of an advanced 80 x 24 video display board.

## 1.2 Description of the Manual

This manual provides a discussion of the theory of operation of the Flashwriter II, and a User's Guide describing 1) when and how to modify the board's electronics and PROM's, 2) how to program for the board, how to adjust the TV monitor, and how to connect the board to keyboard and video. Since the board is not sold as a kit, assembly information and parts list are not included.

## II. THEORY OF OPERATION

A block diagram of the video display module is shown on page 4-5. Each of the blocks is comprised of several integrated circuits as shown on the schematic diagram on page 4-7.

### 2.1 Keyboard Port

Starting with the keyboard port, U46 is an 8 bit latch which internally stores the data from the keyboard coming through J1 when the STB (pin 11) input goes low. A jumper option allows the correct strobe polarity to be selected. U46 contains a service request flip flop which is set by the same strobe edge that latches the data, causing INT to go low (pin 23). This signal can optionally be connected to PINT on the bus (pin 73) for interrupt driven keyboard input, or can be tested by accessing the status port. Two adjacent ports are always occupied by the status and data with the status being the lower one. The port address is decoded by U39 and the associated sections of U27 and U38. A jumper allows the selection of port addresses from 0 and 1 to E and F. (Each pair of ports refers to status and data, respectively.) Signals INPS and INPD enable tristate bus drivers U45 and U21 to gate the INT signal and data onto the bus at the appropriate time. Both inverted and non-inverted status are available, for keyboard drivers using different conventions. The vertical blanking signal is also available, from the status port, for use as a 60Hz clock signal, or for synchronizing data transfers with the vertical retrace.

### 2.2 Horizontal Sync Circuitry

The timing for the characters, horizontal blanking and horizontal sync pulse is provided by U15, U29, U3 and U1. A crystal oscillator at 14.318 MHz provides the clock for all the signals. This is the frequency at which the individual dots making up the characters are displayed. U15 divides this clock by 8 to generate a character clock output every time a new character is to be displayed. This signal is further divided by U29 and U3 to generate a horizontal period of 63.69 micro-seconds. The outputs H0-H6 are binary outputs representing the 80 character positions per line. H7 goes high at the end of the displayed line of characters, and is used as the horizontal blanking signal. At the count of 207, decoded by U2 pin 8, the counter string is preset to the value of 94 and starts counting over again. This signal also triggers U1, a dual one-shot to generate a horizontal sync pulse. The delay of this pulse can be varied by the horizontal position potentiometer to allow centering the display on the TV screen.

### 2.3 Vertical Sync Circuitry

The vertical sync counters U6, U4 and U5 are clocked by the horizontal sync pulse from U1 pin 5 to produce a count from 0 to 261. Each row of characters occupies 10 scan lines. U6 is a decade counter, so it generates a terminal count (TC) every 10 lines. The displayed characters occupy 240 lines, and U19 pin 12 goes low at the count of 240 to blank the display. A vertical sync pulse is generated by a section of U5 and U20 pin 1 which is 2 lines long, from 240 to 242. This is slightly shorter than a standard TV sync signal, and produces a minimum disturbance to the horizontal sync of the TV. The video output remains blanked until the counters are preset to 0 at the count of 261 for a total of 262 scan lines.

### 2.4 Memory Address Multiplexer

The on board memory is multiplexed between the CPU and the sync circuitry. This is done using tristate drivers U40, U41, U28 and the tristate outputs of U16. Thus when the CPU addresses memory, the address bus signals drive the memory address inputs, and while the characters are displayed on the screen, the address inputs are generated by the sync circuitry. One complication is that since 80 is not a binary power, there is not a convenient separation of horizontal and vertical address inputs. 80 is divisible by 16, so the least significant 4 bits from U29 are applied directly to the memory address inputs. The remaining 3 horizontal counter outputs H4-H6 and the vertical sync signals V0-V4 are mapped into 7 bits using a 256 x 8 ROM U16. This effectively maps the displayed characters in a linear fashion into the 2K of address space occupied by the memory. Since  $80 \times 24 = 1920$ , there are 128 locations in RAM that are not displayed on the screen.

If the memory is addressed by the CPU, it will not be able to generate the proper output to be displayed on the screen. This would cause undesirable glitches, or flashes of light on the screen as the display was being written into. To prevent this, access is inhibited by the CPU except during the horizontal retrace interval. U12 provides the necessary arbitration and pulls PRDY (pin 72) low to put the CPU in a wait state until it can access the memory. Two sections of U12 provide delays to ensure that control is transferred properly. U12 pin 13 provides a delay to ensure that the CPU has finished its current memory access cycle, and U12 provides a similar delay to ensure that the memory access time is satisfied before the CPU proceeds. The data bus is buffered by U44 and U33.

### 2.5 Memory Latch

The combined access time of the memory and the character generator ROM exceeds the character period of 558 ns. Thus the data is "pipelined" using U34 and U35 to latch the memory data. This

provides 558 ns access time for both the RAM and character generator. The output of U34, U35 is delayed by one character clock period from the sync counter outputs, while the data strobed into the dot shift register U8 is delayed two character clocks. To compensate for this delay, it is necessary to delay the horizontal blanking signal also. This is done using sections of U35, and the output of pin 12 is H Blank DLD, the delayed horizontal blanking signal.

## 2.6 Character Generator and Shift Register

The dot patterns for each character are generated by U22 and U23. The 8 bit output from these user programmable EPROMs is supplied in parallel to U8 which shifts the dots out at the high dot clock (14.318 MHz) rate. The addressing of U22, 23 is arranged so that there are several options as far as the ROMs are concerned. U22 generates the top 8 lines of each character cell. If only upper case characters are used with no descenders, this is the only ROM required. For the descenders of lower case characters and graphic symbols, a second ROM is required (U23) which generates the bottom two lines of each character cell. If in addition, a full 256 characters are used, U22 is replaced with a TMS 2716. For the 128 character ASCII character set, the most significant memory bit is not required. This is normally jumpered to U7 pin 12 to control the reverse video. If the 256 character set is used, this bit is connected to U22 pin 20 to select the upper half of the ROM. More information on this subject is provided in the User's Guide, Section III of this manual.

## 2.7 Video Combiner

The horizontal and vertical sync signals are available at J2 pin 4,5 for monitors such as the Ball Brothers TV 120 used in the Vector Graphic Mindless Terminal which require separate sync and video. U19 pin 8 is the combined video and blanking signal which is available at J2 pin 3 with the proper polarity for the Mindless Terminal. The sync signals and video are combined in the circuitry associated with U10, and are available at J2 pin 1. The horizontal and vertical sync are first combined in U7 and then summed with the video using the open collector outputs of U10 and the resistive network. The resistor values have been chosen to give the proper sync and video amplitudes and to provide a 75 ohm source impedance to drive a terminated video cable. Very good video rise and fall times are obtained with this circuit. In order to compensate for the limited bandwidth of most TV monitors, some high frequency preemphasis is provided by the 470 pf capacitor shunting the 100 ohm output resistor. If the video display is not satisfactory, it may be improved by changing this value.

## 2.8 Monitor ROM Circuit

A socket is provided for a 2708/2716 ROM to be used as a monitor and/or video driver. U26 selects both the address for the video memory RAM and also the ROM with jumper options every 2K in the upper 16K of memory. A Jump on Reset flip flop consisting of U9 sections has two functions: 1) to disable RAM after the system is powered up or reset; 2) to enable the on-board Monitor ROM at address 0. If the first three instructions of the ROM are JMP XX03, where XX00 is the normal ROM address, then when the system is powered on or the reset key is depressed, these instructions will be executed, causing the CPU to continue executing with the 4th byte of the ROM. After the jump takes place, the circuitry automatically resets the flip flop and restores normal operation of the RAM. Circuitry is also provided to generate MWRITE, a signal produced in some computers by the front panel. This is not required in Vector Graphic equipment as it is generated by the Z-80 CPU board.

1. *Leucosia* *leucostoma* (Fabricius) (Fig. 1).  
2. *Leucosia* *leucostoma* (Fabricius) (Fig. 2).

### 3.1 Modifications of the boundary conditions

The sub-sections will have the following modifications which are to be made by the Board, both to the original and to the new board. In each sub-section the new board is used if it would not make the modification difficult. This section should be read in conjunction with the other sections which constitute the site plan. It is intended to find the location of changes in the site plan. Refer to the diagram on page 47.

Each of the participants  
will have a  
different  
opinion of what  
is carrying out  
the scheme  
and, in  
each area,

### 3.1.1 Creating a New Character

The Flashwriter II stores 128 unique characters in its onboard 96 character ASCII character set plus 16 special function characters. You will find a diagram of this character set on page 4-1. The graphics characters can be used directly in your programming or graphicizing to create a large variety of graphical effects on the video screen. These 128 characters are those that the computer displays on the video screen when the corresponding code is stored in the on-board RAM. The code for each character consists of the lower 7 bits of each stored byte. The eighth bit (bit 7) converts the character into reverse video (black on green) or normal. Otherwise it is normal video. Reverse video versions of the graphics characters are found on page 4-2.

The characters are stored in PROM U20, U21, U22 and U23. Each character consists of an 8 bit field of bits, as illustrated on page 4-1. PROM U22 stores the first 8 lines (lines 0 to 7) and U23 stores the last 2 lines (the decimal part). The lowest addresses on U22 contain the first line of all 128 characters, then come the second lines of all 128 characters and so on, up to the eighth line of all 128 characters. PROM U23 stores the characters with the ninth and tenth bit.

If you wish to replace these characters, you need only create a new pair of PROM's, using the arrangement described above. For a nominal fee, Vector Graphic will do this for you. You must provide Vector Graphic with a drawing of each character, darkening the appropriate cells in an 8 by 10 matrix. Use the blank character form on page 4-3. Note that if you limit yourself to only upper-case characters, not using the bottom two lines in each character, you will now need one 16x8 PROM. To order custom character PROM's from Vector Graphic, please contact the company directly to make arrangements.

You can also create a full P5G character set. To do this, you use a


TMS 2716 2K x 8 PROM or equivalent for U22, and 2708 for U23. The data is organized in the same way as with a 128 character set, except that 256, instead of 128, consecutive addresses contain the first lines of all the characters, and so on for each line in the character matrices. With a 256 character set, you sacrifice the use of reverse video, because all 8 bits of each byte are used to designate the character. Vector Graphic will also create the PROM's for you for a 256 character set, for an appropriate fee. Use both of the blank character forms found on pages 4-3 and 4-4 when sending your character set to Vector Graphic, putting the first 128 characters on the first page, and the second 128 characters on the second page.

The board is shipped jumpered for a 128 character set. Jumpers must be changed as follows for a 256 character set.

	<u>128 character set</u>	<u>256 character set</u>
Area I	2 - 1	Cut 2 - 1
Area B	2 - 4 3 - 1	2 - 1 3 - 4 Cut 2 - 4 Cut 3 - 1
Area E	1 - 3 2 - 5	1 - 3 Cut 2 - 5 2 - 4

### 3.1.2 Changing the Address of the Video Memory

2K of RAM are provided on-board for storage of the current screen image. Since the screen contains only 1920 character locations, the last 128 bytes of this RAM is available for any other purpose. The board is shipped with this RAM addressed at D000. Since the Vector Graphic Extended Systems Monitor assumes this location, do not change it if you are using the video driver in this Monitor, unless you are willing to modify the Monitor on PROM. If you do want to change the address of video memory, a jumper must be changed in Area F. The jumper which determines the address of the RAM goes from pad 2 to one of the 8 pads below it. Each of the 8 pads corresponds to one address, as indicated in the diagram below. Cut the existing jumper and install a new one as required.



### 3.1.3 Putting a Monitor PROM on the Board

The Flashwriter II board is not shipped with a Monitor PROM on the board. However, socket U42 is available for either a 1K 2708 or a 2K 2716 PROM holding a Monitor and/or video driver. This program can be one of the Vector Graphic Monitors (see section 3.2.1) or one you have written yourself (see section 3.2.2.) (Note that in Vector Graphic computers the Monitor PROM resides on the 12K PROM/RAM board.) If you do install a Monitor PROM on the Flashwriter board in U42, it will function if the board is properly jumpered. Refer to sections 3.1.4, 3.1.5, and 3.1.6.

### 3.1.4 Address of the Monitor PROM on the Board

If you choose to use the socket provided on the board for a Monitor and/or Video Driver PROM, you must put a jumper in Area F to specify the address of this PROM. The jumper goes from pad 1 to one of the 8 pads below it. Each of the 8 pads corresponds to one address, as indicated in the diagram in section 3.1.2. Obviously, you cannot use the same block of memory that is used for the on-board RAM.

### 3.1.5 Specifying whether Monitor PROM on Board is 2708 or 2716

If you choose to use the socket provided on the board for a Monitor and/or video driver PROM, the chip used can be either a 1K or 2K chip, i.e. a 2708 or 2716 respectively. The board is shipped to accept a 1K PROM, as determined by the jumpers in Area D. In order to use a 2716 PROM, cut the jumpers from 1 - 4 and from 2 - 3 and replace with a jumper from 1 - 3 and a jumper from 4 to Area M. (There is only one pad in Area M.)


### 3.1.6 Enabling Jump-on-Reset

At this time, the Flashwriter II board is not shipped with a Monitor PROM, and therefore is not responsible for Jump-on-Reset. If you install a PROM on the board, you will want to enable Jump-on-Reset. If this is enabled, when the operator powers on the system or depresses the front panel reset switch, the CPU will automatically read the first 3 bytes of the Monitor PROM on the board. Thus, the first three bytes of the Monitor PROM must be a jump to some other address in memory. Usually this address is simply the next address on the same PROM, namely the beginning address of the PROM plus 3.

In order to enable Jump on Reset, install a jumper in Area C from 1 - 2, and in Area K from 1 - 2. If you are writing your own Monitor PROM, then the program which begins at the 4th byte of the PROM must be an appropriate response to the reset.

### 3.1.7 Changing the Keyboard Port Address

Normally the keyboard is accessed through ports 00 and 01 (status and data, respectively). You can change this to any consecutive pair of ports up to 0E and 0F. This is done by changing the jumper in Area J. Cut the existing jumper. Then, install a jumper from pad 1 to the pad corresponding to the desired port address, as illustrated below.



### 3.1.8 Changing the Polarity of Vertical Sync Signal


The board is shipped to output an inverted vertical sync signal, as required by the Vector Graphic Mindless Terminal. If you are using a video monitor which requires a non-inverted vertical sync signal, then cut the jumper in Area A from 1 - 2, and install a jumper from 1 - 3.

### 3.1.9 Obtaining MWRITE

The composite S-100 signal MWRITE is produced by the Vector Graphic Z-80 CPU board. In other computers, it is produced by the front panel. If your computer does not generate MWRITE, then you will need it in order to write to memory. The Flashwriter II board will generate it if you place a jumper in area G, from 1 - 2.

### 3.1.10 Changing the Polarity of the Keyboard Strobe

There are 4 common types of strobes generated by keyboards to indicate that a key has been depressed, as illustrated below:

**DATA AVAILABLE AT ↓**


The first type is the one used by the keyboard on the Vector Graphic Mindless Terminal. Both it and the fourth type require that the key data be strobed into the Flashwriter keyboard latch on the rising edge of the strobe.. The Flashwriter II board is shipped to strobe the data into the latch on the rising edge. On the other hand, if your keyboard generates the second or third type of strobe, cut the jumper in Area H.

**3.1.11 Using Interrupt Driven Software**

If you want the keyboard to generate an interrupt whenever a key is depressed, put a jumper in Area L from 1 - 2. If this jumper is not in place, then keyboard data can only be obtained by polling the status port. (See section 3.2).

**3.1.12 Supplying a Keyboard with a Negative Voltage Power Supply**

If you have a keyboard which requires a negative voltage power supply in addition to the +5V, and you are technically oriented, then there are pads in Area N of the board to install a zener regulated power supply. The circuit diagram on the left, below, will be completed if you insert the correct resistor and zener in Area N, as shown on the right, below.

AREA  
N

The zener voltage will depend on the keyboard requirements if it is needed at all, and the resistor should be selected to bias the zener with at least 10 mA of current in addition to the current required by the keyboard. For example, with a keyboard requiring 10 mA of current at -6V, the zener could be a IN752A (5.6V) and the resistor could be  $10/.02 = 500$  ohms (470 nominal). The zener power dissipation would be 60 mw and the resistor dissipation would be 200

mw. Use a 1/2 watt resistor to allow for higher supply voltages.

### 3.1.13 Using a Spare Key on the Keyboard for Reset

If your keyboard has an extra key not connected to the keyboard encoder logic, it can be used to reset the system, as an alternate to the reset key on the front panel. This is not possible with the Vector Graphic Mindless Terminal. Simply connect the key so that when it is depressed it grounds pin 11 of J1, the keyboard socket. See section 3.4.3 for a diagram of J1.

This pin is connected to pin 75 on the bus (RESET). When the line is grounded by depressing the key, the jump-on-reset circuit on this or another board will enable the Monitor PROM on the same board.

### 3.1.14 Accessing the 60 Hz Vertical Blanking Signal

Bit 5 of the input status port is low during vertical retrace.

## 3.2 Programming for the Flashwriter II Board

### 3.2.1 Vector Graphic Extended Systems Monitor 3 EV-II

By far the most convenient way to use the Flashwriter II board is through the use of the Vector Graphic Extended Systems Monitor, Version 3, Option EV-II or CV-II. This program comes on a PROM to be installed in position 8 on the Vector Graphic 12K PROM/RAM board. The Monitor is NOT automatically included with any order of the Flashwriter II board, and therefore must be ordered as a separate item. If you are upgrading a system from a Flashwriter I board, the Extended System Monitor used for that board will not work with Flashwriter II. You must order Monitor 3.

In contrast with earlier Vector Graphic Monitors, the video driver in Monitor Version 3 allows you to write anywhere on the screen, either by moving the cursor from the keyboard or entering X,Y coordinates from an assembly language or BASIC program. (BASIC must have POKE, as does M.BASIC provided with Vector Graphic Systems.) It also allows you to toggle reverse video from program or keyboard, and offers several less significant additional features. Both Monitor Version 3 and earlier versions contain keyboard input routines. Option EV-II interfaces to parallel keyboards, while Option CV-II interfaces to serial keyboards as on printing

terminals.

In addition to the video driver, and keyboard input routines, the Version 3 Monitor offers a wide range of useful utility programs, including ASCII Dump, Hex Dump, Jump to Micropolis Bootstrap Loader (D800), Compare Blocks of Memory, Jump to Extension PROM (C400 - the start of MZOS or a user written PROM), Find Two Bytes, Go To and Execute, Input from a Port, Jump to Loaded DOS (jumps to the warmstart location of MZOS or MDOS, whichever is running), Jump to 0000, Move Memory Block, Non-destructive Memory Test, Output to Port, Accessing Program Memory (for displaying and changing consecutive addresses), Compute Checksum, Jump to DC00, Search for Single Byte, Test Memory, Jump to 2A00, Wide Screen ASCII Dump, Exchange Memory Blocks, Keyboard Echo, and Zero or Fill Memory. These routines are accessed when the Monitor Executive routine is running, as indicated by the Monitor prompt \*.

Version 3 of the Monitor contains several methods of displaying characters. Although the documentation to the Monitor describes these, a review here is useful. The basic technique is to call the video driver (CALL C006) with the desired character in the A register. This is sometimes called "sending" a character to the driver. This is the method used by all Vector Graphic operating system software such as MDOS and MZOS to display characters. By itself, this can only be used to display normal alphanumeric characters, those with codes between 20 and 7F (Hex). (The driver converts the codes higher than 7F to the corresponding code from 00 to 7F, by changing the 8th bit from 1 to 0.) Then, only the codes between 20 and 7F are displayed. Any code between 00 and 1F is interpreted as a command rather than a character, or if not a valid command, then ignored.

How then are graphics characters displayed? To get around the above restrictions in order to print characters outside the range 20 to 7F, first put the character you want to print in the B register, then put Hex 05 in the A register, and then call the video driver at C006. If the character is from 80 to FF, then it will be displayed in reverse video if your board is jumpered for reverse video as shipped. If not jumpered for reverse video and you are using a 256 character set, then codes 80 to FF will produce whatever characters are specified in the character generator PROM (see section 3.1.1.) If the character is from 00 to 1F, the corresponding graphics character will be displayed, or whatever other character is stored in the character PROM if you have created your own character set.

cancel, send another Control-T.

### 3.2.2 Displaying Characters Without Using the Vector Graphic Monitor Video Driver

This section is of concern if you are bypassing the Vector Graphic Extended Systems Monitor video driver, or writing your own video driver.

To display a character somewhere on the screen, simply write the corresponding ASCII code into the appropriate RAM location, using the RAM on the Flashwriter II board. Unless you have changed the location of this RAM as described in section 3.1.2, it is the 2K block from D628 to D7FF. Since the screen is 80 x 24, the last 128 bytes of this block are not used. The first location of this RAM corresponds to the upper left-hand corner of the screen, and successive locations move across the screen from left to right, going to the left edge of the next line down at the end of each line.

If the board is used as shipped, the characters which will be produced by each ASCII code are shown on the diagrams on pages 4-1 and 4-2. This includes special graphics characters which you can use to build graphic images such as pictures or large letters. Note that the characters from 30 to 9F are reverse video versions of those from 20 to 1F. Similarly, if you display a character having a code from A0 to FF, it will be the reverse video version of normal alphanumeric characters from 20 to 7F. (This assumes that the board is jumpered for reverse video, as shipped.) As explained in 3.1.1, you may create your own characters to replace those supplied with the board.

If you are writing your own Monitor program, including a video driver, you can if you choose install this PROM on the Flashwriter Board. The socket is labelled U42 on the board. If you do this, you should refer to sections 3.1.3, 3.1.4, and 3.1.5 in order to make appropriate hardware modifications if necessary.

### 3.2.3 Producing Reverse Video

This section specifically covers reverse video, even though it has been discussed in preceding sections. Reverse video refers to displaying a character in black, on a white background. This section is only relevant if the Flashwriter Board is jumpered for reverse video, as shipped from Vector Graphic, rather than for a 256 character set. (See section 3.1.1.)

The easiest way to cause reverse video is to go the Monitor Executive routine (if you have the Vector Graphic Monitor Version 3) by depressing ESC on the keyboard. Then depress Control-T (CTRL and

T keys simultaneously). Any characters displayed after that will be in reverse video, until another Control-T is depressed.

Any character stored in the Video Memory RAM will be displayed as a reverse video character if the 8th bit of the character is a 1. This corresponds to Hex codes 80 to FF. If the 8th bit is 0, i.e. codes 00 to 7F, video will be normal. In other words, if you display a character with a code between 80 and FF, it will be the reverse video version of the corresponding character between 00 and 7F. The chart on page 4-1 shows characters corresponding to 00 to 7F (Hex). On page 4-2 a number of additional graphics characters are shown having codes from 80 to 9F (Hex). Notice that the graphics characters from 80 to 9F are reverse video versions of those from 00 to 1F. In the same way, if you store in video RAM the codes beyond 9F, that is A0 to FF, they will be displayed as the reverse video versions of the normal ASCII characters, having codes 20 to 7F.

There are three ways to store the reverse video characters in video memory. First, you can create the appropriate 8 bit code in a program and then store it in video RAM. For the second and third methods you must have the Vector Graphic Monitor Version 3.

As the second method, you can send the character Control-T (14 Hex) to the video driver. This is how the method given in the first paragraph of this section works. Control-T toggles reverse video, so that any characters sent after it, assuming they are in the displayable range, i.e. between 20 and 7F, will be displayed in reverse video (i.e. the driver will set the 8th bit.) The Control-T itself will not be displayed.

(Sending a character to the video driver means putting the code in the A register and calling C006. The Monitor Executive routine, and M.BASIC and MDOS do this automatically when displaying a character on the screen, so that all you have to do is cause the character to be displayed in any way available. For example, since the Monitor Executive echoes characters as they are entered, just depress Control-T on the keyboard after the Monitor prompt \* in order to toggle reverse video. In contrast, the MZOS executive will pass Control-T (and all other Control characters) only if it is the first character of a line. The CP/M executive will not pass it at all, so that you cannot send a control-T from the keyboard under the CP/M executive.

Third, you can send the character Control-E (05 Hex) to the video driver. Following this, you can put any character code in register B and call C006, and the code will be displayed. If it is in the range 80 to FF, then it will be reverse video because the 8th bit is set in these codes. Refer to the Monitor documentation for more discussion of Monitor commands.

### 3.2.4 Determining Whether a Character is in the Keyboard Buffer

This section is of concern if you are not using the keyboard input routine in the Vector Graphic Monitor. Bit 6 of the status port (usually port 00, unless the board is jumpered as described in section 3.1.6) is high and bit 0 is low when a character is available in the data port. You can test either one of these bits. When the test is successful, simply input the data from the data port (data port = status port + 1).

### 3.2.5 Accessing the Vertical Blanking Signal

For programmers interested in accessing the vertical blanking signal, bit 5 of the status port is low during vertical retrace and high at all other times.

## 3.3 Adjusting Your TV Monitor

If your monitor is the Mindless Terminal from Vector Graphic, then refer to the handbook for the Mindless Terminal instead of this section.

The FLASHWRITER is designed to utilize every line of the TV raster (picture). Therefore, some adjustment of the TV monitor is usually required to make all of the characters visible on the screen. Other adjustments may also be necessary. Most monitors have the following controls, either at the rear of the set, or as in the case of the Hitachi, inside the back panel. Often times an insulated screw driver is necessary to turn the controls.

1. HEIGHT - controls the amplitude of the vertical deflection.
2. VERTICAL LINEARITY - controls the line spacing usually at the top of the picture.
3. WIDTH - controls the amplitude of the horizontal deflection.
4. CENTERING - controls the positioning of the raster on the tube.
5. HORIZONTAL HOLD - sets the frequency of the horizontal oscillator.
6. VERTICAL HOLD - sets the frequency of the vertical oscillator.
7. BRIGHTNESS - sets the background picture brightness.
8. CONTRAST - sets the video amplifier gain.

Begin the adjustment of the set with the HEIGHT and VERTICAL linearity. Fill the screen with a pattern of characters. (If you are using the Vector Graphic Extended Systems Monitor, then enter Z

D000 DFFF 30 following the Monitor prompt. The missing character in the bottom line is normal - it is the cursor location.) Adjust the WEIGHT control, which is usually at the rear of the set, until all the characters fit on the screen with an adequate margin on top and bottom. Notice whether the top line of characters is exactly the same height as the bottom line. If it is not, adjust the VERTICAL LINEARITY control until it is. These controls tend to interact to some degree, so several adjustments back and forth may be necessary until a satisfactory adjustment is obtained. Do not be concerned if the display is not exactly centered from top to bottom. The HORIZONTAL HOLD should now be adjusted so that the control is in the center of the range over which the display is in sync, i.e., no characters are missnapped. For some types of displays, this may be over the whole range. At this point, the horizontal position control on the Flashwriter Board should be adjusted so that the rows of characters are centered on the screen horizontally. This control is the small black potentiometer on the upper left hand corner of the board.

Hopefully, at this point you have satisfactorily adjusted your display. If the characters extend off the sides of the display, it will be necessary to adjust the WIDTH control. Some newer sets do not have WIDTH controls. If you are electronically oriented, you can handle this as follows: You can install a choke in series with the horizontal deflection yoke. Local radio-TV stores may be able to supply a width choke if this is necessary, or it is possible to wind one on a small powdered iron form on a cut-and-try basis. Another possibility is to slightly increase the high voltage if the set has this adjustment.

After this, if the display is not exactly centered, it may be desirable to adjust the centering rings on the deflection yoke. On the rear of the deflection yoke are two metal rings with tabs protruding from them. These rings are magnetized, and by rotating them independently, the display can be shifted in any direction up to 1/2 inch or so.

The adjustment of the BRIGHTNESS and CONTRAST should be so that the background is just barely blacked out or slightly grey, while the characters are just bright enough. Too much contrast will result in excessive overshoot on the left edges of the characters, or "hot spots" in the characters.

### 3.4 Connecting the Board to the Video Display and the Keyboard

This section is only relevant if the board is purchased as a separate item, not already integrated into a computer at the factory.

The 6-pin molex connector, called J2, jutting from the top left corner of the board is used to connect the board to the video

display. The pins are numbered 1 to 6 from the left. Pin 1 is composite video, pin 2 is ground, pin 3 is TTL video, pin 4 is horizontal sync, and pin 5 is vertical sync. Accompanying the board in the same shipping container, you will find a small envelope containing one 6-socket molex connector, and 6 small pins that insert into it. Solder the wires of a cable of your choice onto as many pins as you need. Then, insert these pins into the sockets corresponding to the pins on J2 which you require, as described in sections 3.4.1 and 3.4.2.

As an alternate to using the enclosed 6-socket connector and assembling your own cable, Vector Graphic supplies two cables, factory assembled, which you can use if one or the other meets your needs. They are described in sections 3.4.1 and 3.4.2.

#### 3.4.1 Connecting a Video Display Requiring Separate Sync and Video

Access pins 2, 3, 4, and 5 of J2.

The cable supplied with the Vector Graphic Mindless Terminal comes with an appropriate socket attached. If you have ordered the Vector Graphic Mindless Terminal, then this cable will be enclosed with it. Use of this cable is described in the Mindless Terminal manual. You may discard the socket and insertable pins accompanying the Flashwriter II board.


#### 3.4.2 Connecting a Video Display Requiring Combined Sync and Video

Access pins 1 and 2 of J2. If you are using a monitor having a coaxial cable, you will probably want to assemble a cable having a compatible socket at one end, and install it in the rear of your computer, with the other end connected to J2 of the Flashwriter Board.

You can order from Vector Graphic a cable equipped with a 2-socket molex connector at one end and a BNC (circular) socket at the other end which can be installed in the rear panel of a computer. When ordering, refer to it as the "VBC" cable. Vector Graphic computers have cutouts at the rear which are the right size for this socket.

### 3.4.3 Connecting a Keyboard

The keyboard is connected via a 24-pin dip plug to socket J1 on the right side of the board. The following diagram shows the pin assignments:



The cable shipped with the Vector Graphic Mindless Terminal has a properly wired 24-pin dip plug already attached. Simply plug it in. The use of pins 9 and 11 are discussed in sections 3.1.12 and 3.1.13.

## Vector Graphic Flashwriter II Board

Revision 2 2/7/79

		NORMAL VIDEO															
BINARY DIGITS	4 → 3 → 2 → 1 →	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 1 0 1 0 1 0 1 0 1 0 1 0 1 0 1	0 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0	0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0	0 0 1 1 0 0 1 1 0 0 1 1 0 0 1 1	0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0	0 0 1 1 0 0 1 1 0 0 1 1 0 0 1 1	0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0	0 0 1 1 0 0 1 1 0 0 1 1 0 0 1 1	0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0	0 0 1 1 0 0 1 1 0 0 1 1 0 0 1 1	0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0	0 0 1 1 0 0 1 1 0 0 1 1 0 0 1 1	0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0	0 0 1 1 0 0 1 1 0 0 1 1 0 0 1 1	
HEX 1 DIGITS	0 D7...D0	0 1 2	3 D7...D0	4 D7...D0	5 D7...D0	6 D7...D0	7 D7...D0	8 D7...D0	9 D7...D0	A D7...D0	B D7...D0	C D7...D0	D D7...D0	E D7...D0	F D7...D0		
8765	R0	0000	0001	0010	0011	0100	0101	0110	0111	1000	1001	1010	1011	1100	1101	1110	1111

Vector Graphic Flashwriter II Board

Revision 2 2/7/79

## Vector Graphic Flashwriter II Board


Revision 2 2/7/79

<b>BINARY DIGITS</b>	<b>4 → 0 0</b>	<b>3 → 0 0</b>	<b>2 → 0 0</b>	<b>1 → 0</b>	<b>0 0 1</b>	<b>0 0 1</b>	<b>0 1 0</b>	<b>0 1 0</b>	<b>0 1 1</b>	<b>0 1 1</b>	<b>1 0 0</b>	<b>1 0 0</b>	<b>1 0 1</b>	<b>1 0 1</b>	<b>1 1 0</b>	<b>1 1 0</b>	<b>1 1 1</b>	<b>1 1 1</b>	<b>1 0 1</b>	<b>1 0 1</b>	<b>1 1 0</b>	<b>1 1 0</b>	<b>1 1 1</b>	<b>1 1 1</b>
<b>HEX 1 DIGITS</b>	<b>0</b>	<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>	<b>9</b>	<b>A</b>	<b>B</b>	<b>C</b>	<b>D</b>	<b>E</b>	<b>F</b>								
<b>8 7 6 5 2</b>	<b>D7 .. D0</b>																							
<b>0 0 0 0 0</b>	<b>R0</b>																							
<b>0 0 0 1 1</b>	<b>R0</b>																							
<b>0 0 1 0 2</b>	<b>R0</b>																							
<b>0 0 1 1 3</b>	<b>R0</b>																							
<b>0 1 0 0 4</b>	<b>R0</b>																							
<b>0 1 0 1 5</b>	<b>R0</b>																							
<b>0 1 1 0 6</b>	<b>R0</b>																							
<b>0 1 1 1 7</b>	<b>R0</b>																							

Vector Graphic Flashwriter II Board

Revision 2 2/7/79


\* \* REVERSE VIDEO VERSIONS OF GRAPHICS CHARACTERS  
\* \* REVERSE VIDEO VERSIONS OF ASCII CHARACTERS



80 X 24 VIDEO DISPLAY MODULE BLOCK DIAGRAM

4-6

Vector Graphic Flashwriter II Board



SILK SCREEN  
80X24 DISPLAY BOARD  
VECTOR GRAPHIC

Revision 2 2/7/79

TABLE OF COMMANDS FOR USART							
EOP#	EOP#	INITABLE	D8	INIT	*	LXI	SP,S PTR ESCAPE A
E00P	E00P	00000040	0,0,0,40H,0CEH,27H				INIT STACK DUMP LATCI
E013	E013	CE27					
E015	E015	31D0FFY					
E018	E018	C02FE1					
E01B	E01B	AF					
E01C	E01C	32EAPP					
E01F	E01F	3210FF					
E022	E022	INIT		*	LXI	SP,S PTR CALL XRA	INIT CONTROLLER FLAG
E022	E022	0E03					
E024	E024	0E06					
E026	E026	210PEO					
E029	E029	E033					
E02B	E02B	OC					
E02C	E02C	OC					
E02D	E02D	79					
E02E	E02E	FE09					
E030	E030	20F2					
E032	E032	3E53					
E034	E034	323800					
E037	E037	21C8E6					
E03A	E03A	223900					
E03D	E03D	CDCFE4					
E040	E040	CLBRK					
E040	E040	2AE7FF					
E043	E043	11E9FF					
E046	E046	ED53E7FF					
E04A	E04A	1A					
E04B	E04B	77					
E04C	E04C	31D0FF					
E04P	E04P	2100P0					
E052	E052	220FFF					
E055	E055	C02AE5					
E058	E058	C02FE1					
E05B	E05B	J8P8					
E05D	E05D	E65P					
E05F	E05F	214E00					
E062	E062	E5					
E063	E063	FE04					
E065	E065	CCTBE3					
E068	E068	FE41					
E06A	E06A	D8					
E06B	E06B	FESB					
E06D	E06D	DO					
E06E	E06E	21F9E0					
E071	E071	F5					
E072	E072	87					
E073	E073	85					
E074	E074	6P					
E075	E075	S8					
E076	E076	23					
E077	E077	56					
E078	E078	E8					

```

PAGE 3

;MANY WE GO
IA      4) E
IB
IC
ID
IE
IF
IG
IH
IJ
JK
IK
IL
IM
IN
JO
JP
IQ
JR
IS
IT
IV — £800
IW —
IX
IY
IZ
*** * ***

;READ ADD FROM KEYBOARD
;COUNT OF 4 DIGITS
;16 BIT ZERO
;SPACE?
;CHECK VALUE
;MULT H#16

;4 DIGITS?
;KEEP READING

```

E0E0	3620	SPOT	HVT	N,20H	!PRINT SPACE
E0E0	C37BE3	PTCN	JNP	VIDEO	!PRINT CR
E0DF	362D	CRUF	HVT	N,01H	
E0E1	CDCE00		CALL	PTCN	
E0E4	360A		HVI	A,0NH	
E0F6	18F4		JR	PTCN	
E0E0		*			
E0E3	CD7BE3	STCOVR	CMLL	VIDEO	
E0FB	18FC		JR	SPACE-1	
E0ED		*			
E0ED	FE20	* CHECK FOR INDEX VALUE, CONVERT INDEX	CPI	30H	I<0
E0FF	D8		JR	' '	
E0F0	FE2A	*	CPI	' '	I>9
E0F2	3899		JRC	N,4H	
E0F4	E67F		JNI	5FH	UPPER 6 LOWER C
E0F6	FE11		CPI	'A'	I<A
E0F8	D8		JC	'G'	I>F
E0F9	FE17		CPI	'C'	
E0FB	3F		CNC		
E0FC	D8		RC		
E0FD	CD7BE3	NUM	CALL	VIDEO	
E100	D630		SU1	48	!ASCII BIAS
E102	FE0A		CPI	10	;DIGIT 0-10
E104	3802		JRC	N,0FA	
E106	D607		SU1	7	!ALPHA BIAS
E108	A7	ALFA	ANA	A	;CLEAR CY
E109	C9		RET		;WITH CY CLR/N
E10A		*			
E10A	0E02	* READ 2 DIGITS FROM THE CONSOLE	MVI	C,2	
E10C	18B1		JR	AHFO	
E10E		*			
E10E	CD0F00	* SHORT ROUTINE TO SAVE CODE THICK	CMLL	ANEX	
E111	18AA		JR	ANEX	
E113		*			
E113		* READ FROM CONSOLE TO REG A ***			
E113	CD2FE1	RDIN	CALL	ESCAPE	
E116	28FB		JRZ	RDIN	
E118	FE60		CPI	60H	
E11A	38C0		JRC	PTCN	
E11C	F65F		ANI	SFI	
E11E	18BC		JR	PTCN	
E120		*			
E120	CD2FE1	PAUSE	CALL	ESCAPE	
E123	FE20		CPI	20H	
E125	C0		JNZ		
E126	CD2FE1	#LOOP	CALL		
E129	FE20		CPI	20H	
E12B	C226E1		JNZ	PLoop	
E12C	C9		RET		
E12F	CDCE01	ESCANE-			
E132	CB				
E133	CD41E1				



E20E C9	*	REF	/RETURN W NEW B,C
E20F	*		
E20F	*** ERROR PRINT OUT ROUTINE		
E20F	*		
E20F CDC4E00	PTAD	CALJ.	CRLF PAUSE
E212 CD20E1		MDV	A,H
E215 7C		CALL	PT2
E216 CD26E2		MDV	A,L
E219 7D		JMP	PT2S
E21A C1CE7		PUSH	PSW
E21D F5	ERR	PTAD	CALL
E218 CD0FE2		MDV	A,B
E221 78		PT2S	CALL
E222 CD1CE7		POP	PSW
E225 F1		PUSH	BINI
E226 F5	PT2	PSW	CALL
E227 CD20E2		POP	PSW
E22A F1		JR	BINL
E22B 1804		RAR	RAR
E22D 1F	BINL	RAR	RAR
E22E 1F		RAR	RAR
E22F 1F		RAR	RAR
E230 1F		0FH	AN1
E231 E60F	BINL	AD1	48
E233 C630		CP1	58
E235 FE3A		JC	PTON
E237 DADC80		AD1	7
E23A C607		JMP	PTON
E23C C3DC80			
E23P	*		
E23F 7B	BMP		
E240 95		SUB	L
E241 2002		JR	GOON
E243 7A		MDV	A,D
E244 9C		SBH	H
E245 23	GOON	INX	H
E246 C9		RET	
E247	*	JUMP TO USER RAM	
E247 CDC4E4	USER	CALL	PTSTNG
E24A 55534552		DTW	'USER AREA'
E24E 20415245			
E252 C1		JMP	PR+1C001
E253 C30001			
E256	*	JUMP TO RAM AT PR+1C00	
E256 CDC4E4	RAM	CALL	PTSTNG
E259 48492052		DTW	'11 RAM'
E25D 41CD			
E25F C3000PC			
E262	*	JUMP TO RAM AT 0	
E262 CDC4E4	10004H	CALL	PTSTNG
E265 4C4F2052		DTW	'LO RAM'
E269 41CD			

E260 C30000			*	ZERO OR FILL MEMORY WITH A CONSTANT	
E268			CALJ.	PTSTNG	
E268 CDC4E4		E271 4694C4C	DTW	'FILL'	
E275 A0		E275 CD0EE1			
E276		E279 E5			
E279		E27A CD0AE1			
E27A		E27D EB			
E27D		E27E E3			
E27E		E27F C1			
E27F		E280 71			
E280		E281 CD1FE2			
E281		E284 CB			
E284		E285 16F9			
E285		E287 47			
E287		E288 CDC4E4			
E288		E288 45584348			
E288		E28F 414E4745			
E28F		E293 A0			
E293		E294 1809			
E294		E296 47			
E296		E297 CDC4E4			
E297		E29A 4D4F5645			
E29A		E29E A0			
E29E		E29F CD0EE1			
E29F		E2A2 E5			
E2A2		E2A3 CD0E0			
E2A3		E2A6 EB			
E2A6		E2A7 E3			
E2A7		E2A8 4E			
E2A8		E2A9 E3			
E2A9		E2AA 78			
E2AA		E2AD FEAD			
E2AD		E2AF 2804			
E2AF		E2B0 E3			
E2B0		E2B1 77			
E2B1		E2B2 E3			
E2B2		E2B3 71			
E2B3		E2B4 23			
E2B4		E2B5 E3			
E2B5		E2B6 CD1FE2			
E2B6		E2B9 C4CE0			
E2B9		E2BC 18FA			
E2BC		E2BE		*	NON DESTRUCTIVE MEMORY TEST
E2BE		E2C1 4D454020		PTSTNG	
E2C1		E2C5 43484543		'MEM QIXX'	
E2C5		E2C9 CB			
E2C9		E2CA 210000			
E2CA		E2CD 4E		LXI	
E2CD		E2CE 06FF		C,M	
E2CE		E2D0 70		B,OFF1	
E2D0		E2D1 7E		M,N	
E2D1					





E3E3 32DBFF	* MOVE DN 1 LINE	STA	CURPOS		
E3E6 3ADCFF	LINF	LDA	L,INNO	LIFTCURS	CALJ, POP H
E3E9 FE17		CPI	VERT-1		POP D
E3E9 2023		JNZ	NOSCRL		POP B
E3ED	* SCROLL UP ONE LINE				POP FSW
E3F1 215000	SCROLL	LXI	H,HORIZ		RET
E3F0 275BDFFF		LDD	TOSON		LDA VFL
E3F4 19		DAD	D		STA VFL
E3F5 E0A0	SCR1,	LDI			RET
E3F7 E0A0		LDI			
E3F9 7C	MV	CPI	HORIZ*VERT+PAGE/256		
E3FA FEF7		JNZ	SCRL,		
E3FC 20F7		MV	A,L		
E3FD 7D		CPI	HORIZ*VERT+PAGE+OFF1		
E3FF FC80	ELOP	JNZ	SCRL		
E401 20F2		LDA	LINENO		
E403 3ADCFF	* ERASE BOTTOM LINE	XORC			
E406 FB	EROTL	MVI	B,HORIZ		
E407 0650		MVI	M,SPACE		
E409 3620	ELOP	INR	H		
E40B 23		DCR	B		
E40C 05		JNZ	ELOP		
E40D 20FA		DCR	A		
E40F 3D	NOSCRL	INR	A		
E410 3C		STA	LINENO		
E411 32DCFF		JR	RET		
E414 182C					
E416	* ERASE BEFORE BACKSPACING				
E416 3620	DRACKSP	MVI	H,20H		
E418 3ADBFF		LDA	CURPOS		
E418 A7		ANA	A		
E41C 2824		JNZ	RET		
E41E 3D		DCR	A		
E41F 2B		DCK	H		
E420 3620		MVI	H,20H		
E422 181B		JR	TABRET		
E424 3ADBFF	* MOVE THE CURSOR BACK	LDA	CURPOS		
E427 3D	BACKSP	DCR	A		
E428 F23FE4		JP	TABRET		
E42B 1811		JR	CRET		
E42D 3ADBFF	* TAB OVER TO THE NEXT 8 MULTIPLE	LDA	CURPOS		
E430 F607	CR1	7			
E432 18A9		JR	EDL+3		
E434	* CLEAR THE SCREEN AND HOME UP	CALL			
E434 CD8DE4	FORM	XRA	CLEAR		
E437 AF	ICNE	A			
E438 32DCFF		STRA	LINFO		
E43B 32DFFF		STA	VFL		
E43C AF	* CARRIAGE RETURN	XRA	A		
E43F 32DBFF	TABRET	STA	CURPOS		
E442	* RETURN TO THE CALLING ROUTINE				

E442 CD60F4	RET				
E445 EI	POP				
E446 D1	POP				
E447 C1	POP				
E448 F1	POP				
E449 C9	RET				
E4AA 3ADOFF	TW1DF				
E4AD EB00	E44F 1220FFF				
E452 18EE	E452 18EE				
E454	* MOVE THE CURSOR UP	CURSUP	LDA	LINENO	
E454 3ADCFF	E457 A7		ANA	A	
E458 2E8	E458 2E8		JRZ	RET	
E45A 3D	E458 3ADCFF		DCR	A	
E45B 3ACFFP	STORLN		STA	LINENO	
E45E 18E2			JR	RET	
E460	* CALCULATE MEM ADD FROM CURSOR POSITION	LXI	H,HORIZ+VERT+PAGE		
E460 2180F7	LIFTCURS	LXI	LXI		
E463 1B0FFP		LDA	D,-HORIZ		
E466 3ADCFF		INR	LINENO		
E469 3C	CLOP	DAD	A		
E46A 19		CP1	D		
E46B FE18		WRT	D		
E46D 20FA	E46F ED5B0BFF	CTPN	CLOP	CLOP	
E473 1600	E473 1600		LFD	CURPOS	
E475 19			MVT	D,0	
E476	* REVERSE THE VIDEO	DAD	DAD	D	
E476 7E					
E477 EB80			MOV	A,M	
E479 77			XRI	80H	
E47A C9			MOV	H,A	
E47B	* CLEAR TO END OF SCREEN	CLEND	CALL	WRSPC	
E47B CD96E4	E47B 18C2		JR	RET	
E480	3ADBFF	CLLINE	LDA	CURPOS	
E481 3620		MVI	H,20H		
E485 23		INR	A		
E486 3C		CP1	501		
E487 FE50		JRNZ	JRNZ	CLLINE+3	
E489 20F8				RET	
E48B 18B5					
E48D	* CLEAR THE SCREEN	CLEAR	LXI	H,PAGE	
E48D 2100F0			SILD	TOSCN	
E490 22DFFF			SILD	XYFLAG	
E493 22FAFF			MVI	H,20H	
E496 3620			INR	H	
E498 23			CP1	PAGE/12048/256	
E499 7C			JRNZ	WRSPC	
- E49A FEF0				RET	
E49C 20F8					
E49E C9					
E49F	* PROCESS 1/FAD IN CODE				
E49F					



E49F 3E02 LEDIN MWI A,2  
 E4A1 32BAFF STA XYFLAG DD 27 !ESC  
 E4A4 189C JR RET DO 20071 !X=32 Y=7  
 E4A6 \* SET X AND Y CURSOR POSITIORS DT !VECTOR GRAPHIC  
 E4A6 79 XOR MOV CPI A,C  
 E4A7 FE50 MOV CPI 80  
 E4A9 3802 JRC XING  
 E4AB 3E4F MWI A,79  
 P4AD 1890 JRC TABRET  
 E4AF \* YPOS MOV CPI A,C  
 E4B0 FE18 MOV CPI 24  
 E4B2 3802 JRC YING  
 E4B4 3E17 MWI A,23  
 E4B6 18A3 JRC STORLN  
 E4B8 \* CLSTRP XRA A  
 CURPOS CURPOS  
 CURPOS LIFTCURS  
 CURPOS CALL CLINE  
 CURPOS JR EQU S  
 CURPOS LOCATIONS SPTR+OBJ  
 LINENO DS 1  
 VFL DS 1  
 WIDTH DS 1  
 TSON DS 2  
 TCURPOS DS 2  
 LINE DS 1  
 REVERSE VID FLAG  
 PRINT WIDTH  
 TOP OF SCREEN  
 TEMP POSITION  
 ADDITIONS TO 4.0 MONITOR DS 1  
 ORG PSDND  
 PRINT A STRING CRLF  
 E4C1 CD4FE0 CALL CRLF FIRST  
 E4C4 E3 PTSTNG XTHL  
 F4C5 7E MV A,H  
 E4C6 23 INX H  
 E4C7 E3 XTHL  
 E4C8 A7 NNA A  
 E4C9 CD7BE3 CALL VIDEO  
 E4CC F8 RM  
 F4CD 18F5 JR PTSTNG  
 E4CF 3E04 \* SIGN ON MESSAGE MWI A,4  
 E4D1 CD7BE3 SIGN CALJ, VIDEO  
 E4D4 2150F1 LXI H, PGRE+150H  
 E4D7 E5 PUSH LXI H  
 E4D8 1151F1 D, PGRE+151H  
 E4D9 013000 LXI B,30H  
 E4DE 3612 MWI M,12H  
 E4E0 EPB0 LDTR RD H  
 E4E2 F1 ROP LXI D, PAGE+1A0H  
 E4E3 11A0F1 B,640  
 E4E5 F2D0 LDTR CALL  
 E4E6 OIC4E4 PTSTNG

E4E8 1B MWI A,2  
 E4F2 20071 E4F1 20564543  
 E4F5 5A4F5220 E4F9 47524150  
 E4FD 4B494120 E501 IB  
 E502 2008 E504 20202020  
 E508 404F1E49 E50C 5A4F5220  
 E510 20202020 E514 IB  
 E515 2009 E517 20205645  
 E51B 5B53494F E51F 4B20312E  
 E523 32202020 E527 IB  
 E528 00BD E52A C9  
 E52B CC1E4 PROMPT  
 E52E 4B6F6E3E  
 E532 AO E533 C9  
 RET  
 E534 \* WRITE ASCII DUMP CALL DTII  
 E534 CC4E4 WRSCI I DTII  
 E537 41534349 CALL DTII  
 E53B 19204455 CP1  
 E53F 4B50A0 CP1  
 E542 CD0EE1 CALL TAIXX  
 E545 CD98E5 CNLL HOMECL  
 E548 \* MAKE A RULER FOR ASCII DUMP  
 E54B 78 RULELP MOV A,B  
 E54F 2B10 CP1  
 E551 E013 JRZ  
 E553 2B08 JRZ  
 E555 3E20 MVI  
 E557 CD1E3 REENTR  
 E55A 04 INR B  
 E55B 18FB JR RULELP  
 E55D 3B5C MARKER MVI  
 E55F 18F6 JR  
 E561 78 NUMBER MVI  
 E562 CD2DE2 CNLL  
 E565 1BF3 JR  
 E567 CD79E3 \* TOGGLE REVERSE VIDEO  
 E568 CD79E3 TERMINL WORD1  
 E56A CD4F5 CNLL  
 E56D CD00FE2 PTAD  
 E570 0B3F MVI  
 E572 CD79E5 CNLL  
 E575 FA6A55 JM  
 MAPP1

```

E578 C8          RZ          A,M      POP      H
E579 7E          MOV         B,A      MVT      C,15
E57A 47          MOV         A,E      CALL     SPCZ
E57B 3E05        MV1        CALL     CALL
E57D CD70E3      CALL     VIDEO
E580 CD3FEE      CALL     BMP
E583 C8          RZ          DCR
E584 0D          C          * CHECK TO SET SCROLL POINT
E585 F8          H          WIDTH
E586 18F1        JR          WMP2
E588 * HOME CURSOR, PRINT "ADDR"
HOMEC          CALL     RETTING
E58B CDC1E4      CALL     DB      'T'-64
E58R 14          DB          DTII    'ADDR'
E58C 41444452    DTII
E590 A0          RET
E591 0600        MVI     B,0
E593 3E18        MVI     A,24
E595 32DEF0      STAA    WIDTH
E598 C9          RET
E599 * MAKE A RULER FOR HEX DUMP
HEXRULER      MOV     A,B
E59A FE10        CPI     16
E59C 2806        JR2      HEXRET
E59E CD1CE7      CALL     PT2S
E5A1 04          CALL     INR
E5A2 18F5        JR      HEXRULER
E5A4 CDNE0        MOV     A,B
E5A4 CDNE0        CALL     SPCE
E5A7 CDNE0        CALL     SPCE
E5A9 0600        MVI     B,0
E5AC 78          MOV     A,B
E5AD FE10        CPI     16
E5AF C8          R2          OFH
E5B0 E60F        ANI
E5B2 CD31E2      CALL     BINL
E5B5 04          INR     B
E5B6 18F4        JR      HEXRUL
E5B8 * HEX DUMP ROUTINE
HEXRUL          CALL     PTSTNG
E5B9 CDC4E4      CALL     'HEX DUMP'
E5BF 48455820    DTII
E5C3 A0          RET
E5C4 CD0EF1      CALL     TMEX
E5C7 CD8B85      CALL     HOMEC
E5CA CD99E5      CALL     HEXRULER
E5CD CD79E3      CALL     TTYDO
E5D0 CD79E5      CALL     SETSCRLL
E5D3 CD0FE2      CALL     PTAD
E5D6 E5          PUSH    I
E5D7 DS          PUSH    D
E5D8 0E10        MVI     C,16
E5DA 7E          HI,P2
E5DB CD1CE7      CALL     PT2S
E5DE 23          INR
E5DF 0D          DCR
E5E0 C21WES      JNZ2
E5E3 D1          POP     D

```

```

E5E4 E1          POP      H
E5E5 0E0P        MVT      C,15
E5E7 CDNE0      CALL     SPCZ
E5EA CDNE0      CALL     CALL
E5FD CD79E5      CALL     WMP2
E5F0 FADE5      JM      HLP1-3
E5F3 C9          RET
E5F4 * CHECK TO SET SCROLL POINT
SETSCRLL      LDN
E5F4 3AEFF       DCR     A
E5F7 3D          STA      MDT1
E5F8 32DEFF      CJNZ2
E5F9 2007        LXI     B,PAGE+5@1
E5FD 0150F0      SDOD
E600 ED43DFFF    CTSCRL
E604 C9          * PROGRAM MEMORY
CTSCRL      CALL     DTII
E605 * PROGRAM MEMORY
PROGRAM      CALL     DTII
E608 50524F47    CJNZ
E60C 52414D00    CALL     MDT1
E610 CD8E0      SJR
E613 ED53E1FF    SJR
E617 CD88E5    SJR
E61A CD99E5    SJR
E61D CD79E3    SJR
E620 AF          ARA
E621 32DEFF    SJR
E624 CD88E5    SJR
E627 CD2FE1    SJR
E62A CDDE0      SJR
E62D 2AE1FF    SJR
E630 301A        SJR
E632 FE20        SJR
E634 2846        SJR
E636 FE08        SJR
E638 2845        SJR
E63A FE12        SJR
E63C 2839        SJR
E63E FE15        SJR
E640 282F        SJR
E642 FE17        SJR
E644 2839        SJR
E646 FE1A        SJR
E648 2832        SJR
E64A 18D8        SJR
E64C * MODIFY A MEMORY LOCATION
MODMEM      LJLD
E64C 2AE1FF    SJR
E64F 4F          SJR
E650 3AEFF    SJR
E653 A7          SJR
E654 7E          SJR
E655 280D    SJR
E657 B6F0    SJR
E659 01          SJR
E65A 77          SJR
E65B 3AEFF    SJR

```

E65E	E601		XRL	RTRIN+1	
E660	20FF	JRNZ	JR	CSRT	
E662	1818	RNL	RNL		
E664	17	RNL	RNL		
E665	17	RAL	RAL		
E666	17	RAL	RAL		
E667	17	RAL	RAL		
E668	E6F0	ANI	0F011	C	
E66A	B1	ORA			
E66D	0F	RRC			
E66E	0F	RRC			
E66F	18E9	REMEM	JR		
E671	110UFF	* MOVE UP ONE LINE	LXI	D,-16	
E674	19	CSUP	DAD	D	
E675	1809	* MOVE DOWN ONE LINE	JR	RTRIN	
E677	111000	CSDN	LXI	D,16	
E67A	18F8	* MOVE RIGHT ONE SPACE	JR	CSUP+3	
E67C	CSRT	* MOVE LEFT ONE SPACE	INX	H	
E67C	23	CSRT	JR	RTRIN	
E67D	1801	* MOVE LEFT ONE SPACE	DCX	H	
E67F	2B	CSLT			
E680	*	RTRIN	XRA	A	
E680	AF		STA	WIDTH	
E681	12DEFF		SHLD	TURPOS	
E684	22EFF		MVI	A,'U'-6	
E687	3E15	UPAROW	CALL	VIDEO	
E689	CD1BE3		JR	PLOOP	
E68C	1896	* PRINT A LINE CONTAINING ((H))	LIDL	TCURPOS	
E68E	2AE1FF	PRFLINE	PUSH	H	
E68F	2AE1FF		POP	D	
E691	E5		MOV	A,L	
E692	DI		ORI	0F11	
E693	7D		MOV	E,A	
E694	F60F		0FH	0F0H	
E695	5F		MOV	L,A	
E697	F6F0		MOV	CALL	
E699	6F		CALL	HLP1	
E69A	C0FES	* NOW PUT CURSOR WHERE IT GOES	CALL	LIFTCUR	
E69D	C160E4		BUILD	TCURPOS	
E6A0	2AE1FF		MVJ	A,L	
E6A3	7D		MVJ	0F11	
E6A4	E60F		DCR	L,A	
E6A6	6F		JM	PCOUNT	
E6A7	3F05		ADJ	3	
E6A9	2D		JR	PLCP1	
E6AA	FAB1E6		MVJ	L,A	
E6AD	C603		DCR	WHTH	
E6AF	18F8		JM	LDA	
E6B1	6F		ADJ	L	
E6B2	3ADCF5				
E6B5	85				
		POCOUNT			

E6B6	*	A = 5+3*LW	STA JRP	CURDOS LIFTORS
E6B6	3200FF		STI	
E6B9	C360E4		JMP	
E6BC				
E6C0	*	DISPLAY REGISTERS	CALL DTII	PTISING 'REGISTERS'
E6C3	OCDAE4			
E6F0	5245749			
E6C3	53544552			
E6C7	D3	*	DISPREGS AFTER EXIT FRM REG 7	
E6C8	E3	DUMPREGS	XTHL	
E6C9	F5		PSW	
E6CA	QD22E7		CALL DISPHREGS	
E6CD	2B		DCX H	
E6CE	QD0FE2		CALL PRND	:GET BREAK ADD
E6D1	E1		POP H	
E6D2	C5		PUSH B	
E6D3	QD77E7		CALL PRFLGS	
E6D6	C1		POP B	
E6D7	QD12E2		CALL PTAD+3	:PRINT AF
E6DA	E1		POP H	
E6DD	22EJFP		SHLD HLT/HP	
E6DE	QD98E7		CALL FTIREE	:PRINT B D II
E6E1	D0E5		PUSH IX	
E6E3	E1		POP H	
E6E4	QD12E2		CALL PTAD+3	:PRINT IX
E6E7	FDE5		PUSH IY	
E6E9	E1		POP H	
E6EA	QD12E2		CALL PTAD+3	:PRINT IY
E6ED	210000		LXI H,0	
E6F0	39		DAD SP	
E6F1	225FFF		SHLD SPTEMP	
E6F4	QD12E2		PTAD+3	:PRINT SP
E6F7	08			
E6F8	F5		PSW	
E6F9	E1		POP H	
E6FA	QD12E2		CALL PTAD+3	
E6FD	D9		EXX	
E6FE	QD98E7		CALL PRIREE	
E701	D9		EXX	
E702	0A		LDAX B	
E703	QD1CE7		CALL PT25	
E706	I4		LDAX D	
E707	QD1CE7		CALL PT25	
E70A	2AC3FF		ULD HIJTPHP	
E70D	7E		MV A,M	
E70E	QD1CE7		CALL PT25	
E711	2AE5FF		ULD SPTEMP	
E714	F9		SPIL	
E715	E1		POP H	
E716	QD12E2		CALL PTAD+3	:CLEAR BREAKIN
E719	C340E0		JRP CLRHK	
E71C		PT25	CNL	PT2
E71F	C3DNE0		JMP SPCE	:PRINT 2 CHAR
E722	*	DISPLAY REGISTER HEADER ON SCREEN		:PRINT' SPACE

PME 21

DISPRES	CALL	PRINTING
E7222 CDC1E4	DB	"1"-64
E7225 14	DT	'ADDR FLAGS AF BC DE'
E7226 41444452		
E722A 202424320		
E722B 47532020		
E722C 41462020		
E722D 20204445		
E722E 4C202020		
E7246 49582020		
E724A 20495920		
E724F 20205350		
E732 20	UT	AFF
E733 20204146	DB	27H
E737 27	UT	BC
E738 20204243	DB	27H
E73C 27	UT	DE
E73D 20204445	DB	27H
E761 27	UT	HL
E762 2020484C	DB	27H
E766 27	UT	BD BD B1 ESP
E767 20404220		
E768 40442040		
E76F 48204053		
E773 5020	DB	"1"+64
E775 94	RET	
E776 C9		
E777	*	PRINT FLAGS
E777 015A40	PRFLGS	LAI
E777A C1W7E7		CALL
E777D 014301		B,405A1
E778 CDA7E7		MASKFLG
E779 014D80		LAI
E77E C1W7E7		B,143H
E77F 014504		MASKFLG
E780 014810		LAI
E782 C3W7E7		B,040D1
E785 C3DAE0		MASKFLG
E798 C12E2		LAI
E799 E5	PTURCE	CALL
E799 C5		B,445H
E79A E1		MASKFLG
E79B CD12E2		LAI
E79C D5		B,044B1
E79D E1		MASKFLG
E79E CD12F2		LAI
E79F E1		B,445D
E7A0 C12E2		MASKFLG
E7A1 E1		LAI
E7A2 C12E2		B,445D
E7A3 E1		MASKFLG
E7A4 C12E2		LAI
E7A5 C12E2		B,445D
E7A6 E1		MASKFLG
E7A7 7D		LAI
E7AB AE20		B,445D
E7AC CA1BE3		MASKFLG
E7AD CA1BE3		LAI

E7AE 79		MVN	A,C
E7AF C37BE3	JMP	VINFO	
E7B2			
E7B2	* SET BREAKPOINT		
E7B2 CC4E4	SETBK	CAL.L	PTSTNG
E7B5 42524541		DTH	'BREAK AT'
E7B9 4B204154			
E7B0 A0			
E7B2 COODEO			
E7C1 IA			
E7C2 3269FF			
E7C5 ED51E7FF			
E7C9 3EFF			
E7CB 12			
E7CC C9			
E7CD			
E7CD COOC4			
E7D0 455B5420			
E7D4 434F4D40			
E7D8 DB05			
E7D8 DB05	RECEIVE	IN	5
E7DA E602		ANI	2
E7DC 2805		JRZ	NEXCR
E7DE DB04		IN	4
E7E0 CD78E3		CALL	VIDEO
E7E3 CD2PE1	NEXCR	CALL	ESCAPE
E7F6 28F0		JRZ	RECEIVE
E7EB D304		OUT	4
E7EA 18EC		JR	RECEIVE
E7EC			
E7FC	* TEMPORARY STORAGE LOCATIONS FOR REGISTERS, ETC.	TURPOS+2	
FFE3	HLTIMP	ORG	2
FFE5	SPTEMP	DS	2
FFE7	BKPTLOC	DS	2
FFE9	BIRCODE	DS	1
FFEA	XYFLAG	DS	1

